

Telephone Number Change Procedure
Panasonic Model KX-4925 Terminals
(Internal Printer, No Screen)

1. Turn Power Switch ON.
2. Press Function Key "**F1**" (in top row of "chiclet" keys)
3. Locate the station index that has information in the corresponding row which contains our old service (usually row "A"). Remember the line entries. The existing entry will be used in step i.
4. Press Function Key "**F5**", follow instructions below. **Bold** items are user entered information.

- i. <<Station Index>>:=____ (Enter line letter of new entry above)
- ii. Double Index! Change Contents?(Y/N):=**Y**
- iii. Edit/Clear/Include:=**E** (Do not press BREAK Key!)
- iv. <Name>:=____ (There should be a name currently existed call TMK or MLS; press **Return**)
- v. <Phone NO>:=____ (Type in new Phone Number and press **Return**)
(**Oahu**: 441-0001, **Maui**: 442-0001, **Hilo / Kona**: 934-9058 / 443-0001 and **Kauai**: 246-2800)
- vi. <Private Paramter>(Edit/Default/System/Clear?):= (Press **E** Key)
- vii <Paramters Parameter> (1-17):= (Press **2** Key)
- viii Parity:= (Press **N** key)
- ix Word length:= (Press **8** key)
- x Stop bits:= (Press **BREAK** Key)
- xi < Paramters Parameter> (1-17):= (Press **9** Key)
- xii Transmit Code on 'BACK SPACE':= (Press **D** Key)
- xiii Detect XON/XOFF busy code:= (Press **Y** Key)
- xiv Transmit XON/XOFF busy code:= (Press **BREAK** Key)
- xv <Paramters Parameter> (1-17):= (Press **BREAK** Key)
- xvi. <Private ABM>(Edit/System/Clear):= (Press **BREAK** Key)
- xvii.<Auto Logon>(Edit/Clear?):= (Press **E** Key)

- | Step | Command | Characters |
|------|---------|---|
| 1 | | (Press T Key and hit Return) |
| | | Press the Down Arrow Key "↓" |
| 2 | | (Press O Key and type :) Press the Down Arrow Key "↓" |
| 3 | | (Press T Key and type research3 and Press Return) |
| | | Press the Down Arrow Key "↓" |
| | | (Type research1 for oahu, research2 for Maui and research3 for Big Island) |
| 4 | | (Press O Key and type :) Press the Down Arrow Key "↓" |
| 5 | | (Press T Key and type mlshawaii and Press Return) |
| | | Press the Down Arrow Key "↓" |
| 6 | | (Press E Key) |

After you complete steps1-6, you will have a screen that looks something like the one on **FIGURE 1** below. As indicated below, press the **BREAK** key 3 times.

The entry for the new service is now programmed into your terminal. To access this new entry, press the Online Button and then the letter of your new entry. It will act the same way as your old entry. The only difference is the new entry is dialing a different phone number.

```
AUTO LOGON      Index := A      Auto ans  FEB 9 '87  1:25 AM REPLACE
```

STEP	COMMAND	CHARACTERS
1	TRANSMIT	h
2	TRIGGER ON	:
3	TRANSMIT	research36
4	TRIGGER ON	:
5	TRANSMIT	mshawaii6
6	EXIT	

FIGURE 1